


# REPAIR PARTS LIST FOR AA-8.5E JACK

Item No.	Part No.	Part Name	No. Req.
1	AA85.05P-4	Base	1
2	1.16	Valve Ball	1
3	51.16	Valve Ball	1
4	BA85.183	Outlet Valve Spring	1
5	5159.167	Valve Plug Gasket	1
6	CB9.185-1	Valve Plug	1
7	CB9.335	Release Valve Packing Washer	1
8	1.74	Release Valve Packing	1
9	CB9.11-1	Release Valve Packing Nut	1
10	BA85.10A-1	Release Valve Spindle	1
11	B155.026	Name Plate	1
12	W78.03	Drive Screw	4
13	BA85.18-1	Oil Strainer Screen	1
14	AA85.30-3	Cylinder	1
15	AA85.40-3	Plunger	1
16	AA85.39	Plunger Sleeve	1
17	AA85.28-1	Plunger Adjusting Screw	1
18	AA85.45-1	Saddle	1
19	AA85.29-2	Plunger Ring	1
20	M73.41-1	Plunger Cup	1
21	AA85.43	Plunger Cup Washer	1
22	AA85.120	Plunger Cup Retaining Nut	1
23	AA85.25-2	Reservoir	1
24	C9.37	Filler Plug Gasket	1
25	C9.22-1	Filler Plug	1
26	AA85.20-2	Top Cap	1
27	CA11.76	Plunger Packing	2
28	AA85.21	Gland Nut	1
29	CB9.51-1	Pump Plunger	1
30	F11.53	Pump Cup	1


Item No.	Part No.	Part Name	No. Req.
31	F11.52	Pump Cup Spreader	1
32	CB9.55	Pump Cup Retaining Nut	1
33	CB9.50-1	Pump Cylinder	1
34	5.75	Pump Packing	2
35	CB9.54-1	Pump Gland Nut	1
36	CB9.60-2	Beam	1
37	CB9.61-2	Beam Handle Pin	1
38	CB9.57-1	Beam Pin	1
39	1.53	Cotter Pin	3
40	BA85.57-1	Base Link Pin	2
41	BA85.62-2	Link	1
	H12	Handle	1
		Blackhawk Oil No. LX21 5/8 Pt. (17 Cu. In.)	
	CJ100.038	Decal	1
		SUB-ASSEMBLIES	
	AA85.05C-4	Tested Base Items 1 thru 6 incl. end 12 & 13	
	AA85.40C-3	Complete Plunger Items 15 thru 22 incl.	
	CB9.50A-1	Pump Assembly Complete Items 29 thru 35 incl.	
	CB9.51A-1	Pump Plunger Complete Items 29 thru 32 incl.	
	CB9.60A-2	Beam & Link Complete Items 36 thru 41 incl.	
	CB9.60B-2	Beam & Beam Handle Pin Items 36 & 37	



REPAIR PARTS SHEET FOR AA-8.5E  
HYDRAULIC JACK

Part List on Reverse Side





# REPAIR PARTS SHEET FOR AA-8.5E HYDRAULIC JACK

BLACKHAWK

**Parts List on Reverse Side**